



CORNELIUS INC ■ One Cornelius Place ■ Anoka, MN 55303-6234

Telephone (800) 238-3600

Facsimile (800) 535-4231

INSTALLATION INSTRUCTIONS

WATER-ONLY LEVER KIT FOR UF-1 VALVE

KIT P/N 3297

Only qualified personnel should perform this procedure.

1. Remove Cover from the dispensing valve by Lifting front cover up 1/2 inch and pulling forward. Slide rear cover forward 1/2 inch and lift off.
2. Remove the valve from the mounting block.
3. Remove Nozzle by turning counterclockwise and gently pulling down.
4. Remove Bottom Plate by releasing snap fit clips with your thumbs, (on both sides), and pivot the Bottom Plate down.
5. Use pliers to break out web in Bottom Plate for the Water Lever (see illustration below).
6. Install the Bottom Plate by inserting the Bottom Plate rear tabs and then pivot up to secure the snap fits.
7. Install the nozzle by pushing up and turning clockwise.
8. Install Water Lever P/N 1935 (see illustration below). Make sure wires do not interfere with the lever, and lever engages with stem of the banjo. Do Not over-tighten the shoulder screw.
9. Install the valve back on the mounting block.
10. Replace cover by reversing step 1.

