

**In this Issue:**

CED Leg Install and Handling.....2

**Technical Bulletin Distribution:**

The Lancer Engineering Department publishes a Technical Bulletin every other month. To subscribe or unsubscribe from the Tech Bulletin, go to [lancerworldwide.com](http://lancerworldwide.com). Lancer Installation and Service Manuals, Instruction Sheets, previous Technical Bulletins, and a complete index of Technical Bulletin articles are also available at [lancerworldwide.com](http://lancerworldwide.com). For general questions about the Tech Bulletin, email [custserv@lancerworldwide](mailto:custserv@lancerworldwide) or call (888) 846-6729.

**Contact Information:**

- Lancer Sales:** (800) 729-1500
- Lancer Customer Service:** (800) 729-1500
- Lancer Warranty:** (800) 729-1550
- Lancer USA:** (210) 310-7000
- Canada:** (210) 310-7187
- Latin America:** (210) 310-7000
- International Sales:** (210) 310-7063
- Europe:** 32-2-755-2390
- Australia/New Zealand:** 61-8-8268-1388
- Email:** [custserv@lancerworldwide.com](mailto:custserv@lancerworldwide.com)
- Lancer Website:** [www.lancerworldwide.com](http://www.lancerworldwide.com)

Lancer® is a registered trademark of Lancer Corp.



### In this Issue:

CED units are to only be transported, or moved, with legs not attached. Do not attempt to slide unit while legs are installed, this may damage the bottom plate. Additionally, attempting to slide the unit can present a tipping hazard. Legs are only to be installed when the unit is at a permanent location. Unit should only be lifted from bottom metal structure.

#### Recommended Method of Leg Installation:

1. Remove refrigeration and carbonation decks from unit.
2. Place unit on side.
3. Proceed to install legs as shown below, turning clockwise until securely in place.



Unit shown on its side



Legs installed



Do not push or slide